

OPERATOR'S MANUAL

Precision Abrasive Machinery, Inc.

14200 W. COMMERCE RD. * P.O. BOX 43 * DALEVILLE, INDIANA 47334
Phone (765) 378-3315 * Fax (765) 378-3316

3/20/2002

AUTOMATIC CARBIDE ROD CUT OFF SAW Version #6.1 OPERATOR'S MANUAL

TABLE OF CONTENTS

- OPERATOR INTERFACE SCREENS AND EXPLANATION; See Page 2
- FAULT SCREENS See Page 22-29
- ENGINEERING SCREENS See Page 30-45
- Rod End Sensor to Wheel Offset Calculations. See page 46

OPERATOR'S MANUAL

SCREEN #1, HOME SCREEN

AUTOMATIC CARBIDE CUT OFF SAW ~ VER 6.1					
~ MAIN MENU ~					
F2 = OPERATOR SETUP & MANUAL					
F3 = AUTO MODES OF OPERATION No Faults					
F4 = FAULTS if Flashing--> FAULTS !!					
ALARM	SETUP	MODES	FAULT	_____	ENG'R
F1	F2	F3	F4	F5	F6

This is the **Main Menu** Screen for the **Automatic Carbide Cut Off Machine**. When the machine is powered up either by choice or power failure, the "**FAULTS!**" prompt will be flashing. The Operator then needs to press the '**FAULT**' Button (F3) and follow the prompts from the **FAULT** Screen. See page 21. When ALL Faults have been solved, the Operator will return back to this Screen. The "FAULTS!" prompt will be gone and "**No Faults**" prompt will be seen.

Next the Operator will be able to select:

F1: ALARM -- Clear any Input over limit values made by Operator.

Press IF any Inverted (dark) Message is flashing at the very top of the Operator Screen.

F2: SETUP -- OPERATOR SETUP (See page 3)

F3: MODES -- MODES OF OPERATION (See page 15)

F4: FAULT -- VIEW AND CLEAR ANY FAULTS (See page 22)

F5: Not used.

F6: ENG'R -- Special Engineering Setup (See page 30)

OPERATOR'S MANUAL

SCREEN #2, OPERATOR SETUP SCREENS, F1 FROM MAIN MENU

OPERATOR SETUP FUNCTIONS					
F2 = Setup INFORMATION					
F3 = Manual WHEEL MOTOR & COOLANT					
F4 = Manual JOG Axis and CLAMPS					
F5 = HOME ALL AXIS					
MENU	INFO	WM+C	JOG	HOME	FAULT
F1	F2	F3	F4	F5	F6

F1: MENU -- Return to Main Menu.

F2: INFO -- Press this key to view the screens necessary to setup or revise the information to cut the carbide rods. (See page 4).

F3: WM+C -- Press this key to view the screens necessary to Manually operate the Cutting Wheel Motor and Coolant Solenoid. (See page 13).

F4: JOG --- Press this key to view the screens necessary to Manually Jog the Axis and operate the Vee Clamps. (See page 10).

F5: HOME -- Press this key to Home the Rod Pusher and Wheel Head Axis.

F6: FAULT - Press this key if a "Faults!" is flashing.

OPERATOR'S MANUAL

SCREEN #3, SETUP INFORMATION, F2 FROM OPERATOR SETUP SCREEN

OPERATOR SETUP INFORMATION					
F2 : TOGGLE Front Nip [NO / YES]					
F3 for NIP Amount = x.xxx In.					
F4 for Cutting Wheel WIDTH = x.xxx In.					
F5 for Rod DIAMETER = x.xxx In.					
SETUP	TOGGL	NIP	WIDTH	DIA	MORE
F1	F2	F3	F4	F5	F6

- F1: SETUP** - Press this key to return to Operator Setup. (See page 3).
- F2: TOGGL** - Press this key to toggle the Front Nip option (No or Yes).
- F3: NIP** --- Press this key to access the Nip Amount value and then use the numeric key pad to input the needed value. Then press the [↵] key to accept the new value.
- F4: WIDTH** -- Press this key to access the Cutting Wheel Width value and then use the numeric key pad to input the needed thickness. Then press the [↵] key to accept the new value.
- F5: DIA** -- Press this key to access the Rod Diameter value and then use the numeric key pad to input the needed diameter. Then press the [↵] key to accept the new value.
- F6: MORE** - Press this key to go to the next set of operator screens.

OPERATOR'S MANUAL

SCREEN #4, SETUP INFORMATION, F6 FROM SETUP SCREEN #3

OPERATOR SETUP INFORMATION					
F2 for PRIMARY Cut Length = x.xxx In.					
F3 for Number of Primary CUTS = xx Cuts					
F4 for SECONDARY Cut Length = x.xxx In.					
BACK	PRI	CUTS	SEC	_____	MORE
F1	F2	F3	F4	F5	F6

F1: BACK -- Press this key to go back 1 screen.

F2: PRI --- Press this key to access the Primary Cut Length value and then use the numeric key pad to input the needed value. Then press the [↵] key to accept the new value.

F3: CUTS -- Press this key to access the Number of Primary Cuts value and then use the numeric key pad to input the needed value. Then press the [↵] key to accept the new value.

F4: SEC -- Press this key to access the Secondary Cut Length value and then use the numeric key pad to input the needed thickness. Then press the [↵] key to accept the new value.

F5: NOT USED.

F6: MORE - Press this key to go to the next set of operator screens.

OPERATOR'S MANUAL

SCREEN #5, SETUP INFORMATION, F6 FROM SETUP SCREEN #4

OPERATOR SETUP INFORMATION					
F2 for MAJOR Cut Speed = xx.xx I.P.M.					
F3 : TOGGLE Break Thru Speed ? [Yes/No]					
F4 for Break Thru Rod PERCENT = xx %					
F5 for Break THRU Speed = xx.xx I.P.M.					
BACK	MAJOR	TOGGL	PCENT	THRU	MORE
F1	F2	F3	F4	F5	F6

F1: BACK -- Press this key to go back 1 screen.

F2: MAJOR --- Press this key to access the Major Cut Speed value and then use the numeric key pad to input the needed speed in IPM. Then press the [↵] key to accept the new value.

F3: TOGGL - Press this key to toggle the Break Through Speed option "No or Yes".

F4: PCENT - Press this key to access the Break Through Rod Percentage value of total rod diameter and then use the numeric key pad to input the needed percent. Then press the [↵] key to accept the new value.

F5: THRU -- Press this key to access the Break Through Speed value and then use the numeric key pad to input the needed speed in IPM. Then press the [↵] key to accept the new value.

F6: MORE - Press this key to go to the next set of operator screens.

OPERATOR'S MANUAL

SCREEN #6, SETUP INFORMATION, F6 FROM SETUP SCREEN #5

OPERATOR SETUP INFORMATION					
COMPENSATIONS -- See CHART for Settings					
+F2/-F3 for SENSOR to Wheel = x.xxx In					
If the First Cut Length is short, then					
increase Sensor value.					
BACK	+ SEN	- SEN	CHART	_____	MORE
F1	F2	F3	F4	F5	F6

F1: BACK -- Press this key to go back 1 screen.

F2: + SEN - Press this key to increase the Sensor to Wheel distance.

F3: - SEN - Press this key to decrease the Sensor to Wheel distance.

The Sensor to Wheel distance determines whether the first rod cut length is the correct amount. If the first rod cut length is short, then increase the Wheel to Sensor amount.

F4: CHART - Press this key to view the chart for the approximate offset distance factor from the mean sensing distance for each diameter listed. (See page 9).

F5: Not used.

F6: MORE - Press this key to go to the next set of operator screens.

OPERATOR'S MANUAL

SCREEN #7, SETUP INFORMATION, F6 FROM SETUP SCREEN #6

OPERATOR SETUP INFORMATION					
+F3/-F4 for WHEEL Wear Comp = x.xxx In					
If the Wheel does not cut through the					
Rod, then increase Wheel Wear value.					
F5 : To Reset Value to Default					
BACK	MENU2	+ WHL	- WHL	RESET	_____
F1	F2	F3	F4	F5	F6

F1: BACK -- Press this key to go back 1 screen.

F2: MENU2 - Press this key to return to the Operator Setup Functions Menu Screen. (See page 3).

F3: + WHL -- Press this key to increase the amount of Wheel Wear.

F4: - WHL -- Press this key to decrease the amount of Wheel Wear.

The Wheel Wear amount determines whether the cutting wheel passes through the rod. If the rod has not been cut through, then increase the wheel wear amount.

F5: RESET - Press this key to reset the Wheel Wear Compensation to its default value.

F6: MORE - Press this key to go to the next set of operator screens.

OPERATOR'S MANUAL

SCREEN #8, SETUP INFORMATION, F4 FROM SETUP SCREEN #6

Sensor to Wheel OFFSET Comp. Per O.D.					
Distance Ref. =x.xxx		3/8" OD = xx.xxx			
1/16" OD = xx.xxx	1/2" OD = xx.xxx				
1/8" OD = xx.xxx	3/4" OD = xx.xxx				
1/4" OD = xx.xxx	1" OD = xx.xxx				
BACK	_____	_____	_____	_____	_____
F1	F2	F3	F4	F5	F6

This is a chart with the approximate offset values to be added or subtracted, check sign (-), from the reference distance. The Supervisor or Engineer sets these values in the Engineering section.

F1: BACK -- Press this key to go to screen #6. (See page 7).

F2: Not used.

F3: Not used.

F4: Not used.

F5: Not used.

F6: Not used.

OPERATOR'S MANUAL

SCREEN #9, MANUAL JOG SETUP, F3 FROM SETUP SCREEN #2

Manual Jog: TOOL BED Axis [FAULTS!!]					
POSITION = xx.xxx In SPEED =[Fast/Slow]					
Note: Jog Axis Up/Back to Fill with Rods					
Then Jog Axis UP until Rod falls in VEE					
F3: Toggle Rod Vee CLAMPS =[CLOSED/OPEN]					
MENU2	SPEED	CLAMP	FAULT	_____	NEXT
F1	F2	F3	F4	F5	F6

This screen is used to allow the Operator to jog the Tool Bed Axis up or back to make room to load the rods to be cut on the flat bed. After filling the flat bed, then the Operator needs to jog the axis up until the rods falls onto the Pusher Vee. This will set the Tool Bed Axis starting position and the index timing.

F1: MENU2 - Press this key to return to the Operator Setup Functions Menu Screen. (See page 3).

F2: SPEED - Press this key to toggle the Axis speed Fast or Slow.

F3: CLAMP - Press this key to toggle the Rod Vee Clamps state of either closed or open.

F4: FAULT - Press this key if "Faults!" is flashing.

F5: Not used.

F6: NEXT - Press this key for the next screen to operate the Rod Pusher Axis, or next again for the Wheel Head Axis.

OPERATOR'S MANUAL

SCREEN #10, MANUAL JOG SETUP, F6 FROM SETUP SCREEN #9

```
Manual Jog: ROD PUSHER Axis  [FAULTS!!]  
POSITION = xx.xxx In  SPEED =[Fast/Slow]  
Note: Use to Jog and Set Rear Limit  
Switch and to Test Axis Movement.  
F3: Toggle Rod Vee CLAMPS =[CLOSED/OPEN]  
BACK      SPEED    CLAMP    FAULT    _____    NEXT  
F1        F2        F3        F4        F5        F6
```

This screen is used to allow the Operator to jog the Rod Pusher Axis forward or backward to make adjustments and set the Rear limit switch for the length of rods used. The Jog function is also used to test the axis for trouble shooting problems. The Forward limit switch has been set by the manufacturer and should not be moved.

F1: BACK -- Press this key to go back to the previous Axis screen.

F2: SPEED - Press this key to toggle the Axis speed Fast or Slow.

F3: CLAMP - Press this key to toggle the Rod Vee Clamps state of either closed or open.

F4: FAULT - Press this key if "Faults!" is flashing.

F5: Not used.

F6: NEXT - Press this key for the next screen to operate the Wheel Head Axis.

OPERATOR'S MANUAL

SCREEN #11, MANUAL JOG SETUP, F6 FROM SETUP SCREEN #10

Manual Jog: WHEEL HEAD Axis [FAULTS!!]					
POSITION = xx.xxx In SPEED =[Fast/Slow]					
Note: Use to Jog, change Cut Off Wheel and to Test Axis Movement.					
F3: Toggle Rod Vee CLAMPS =[CLOSED/OPEN]					
BACK	SPEED	CLAMP	FAULT	_____	JMENU
F1	F2	F3	F4	F5	F6

This screen is used to allow the Operator to jog the Wheel Head Axis forward or backward to change the Cut Off Wheel, to clear a jamb, or view the maximum forward travel distance to set the software over travel. The Jog function is also used to test the axis for trouble shooting problems. The limit switches have been set by the manufacturer and should not be moved.

F1: BACK -- Press this key to go back to the previous Axis screen.

F2: SPEED - Press this key to toggle the Axis speed Fast or Slow.

F3: CLAMP - Press this key to toggle the Rod Vee Clamps state of either closed or open.

F4: FAULT - Press this key if "Faults!" is flashing.

F5: Not used.

F6: JMENU - Press this key to go to the Tool Bed Axis screen #9. (See page 10).

OPERATOR'S MANUAL

SCREEN #12, MANUAL Motor & Coolant, F4 FROM SETUP SCREEN #2

```
OPERATOR SETUP; -- Manual --
F3 : STOP/START
      Wheel Head Motor = [Status]
F5 : Toggle COOLANT Solenoid
      Coolant Solenoid = [Status]
BACK  _____  S/S  _____  COOL  _____
F1      F2      F3      F4      F5      F6
```

This screen is used to allow the Operator to manually stop or start the Wheel Head Motor to check the status of the Cut Off Wheel or to check the motor for noise.

Also, a new Vee Clamp assembly may need to be checked for clearance to allow the cut off wheel to move through the slot between the carbide wear strips. Use this and Manual Jog Axis function to check for clearance, left/right alignment, and parallel to slot.

F1: BACK -- Press this key to return to the Operator Setup screen.

(See page 3).

F2: Not used.

F3: S / S - Press this key to stop or start the Wheel Head Motor.

[Status] will show active state of [Off] or [On].

F4: Not used.

F5: Not used.

F6: COOL -- Press this key to toggle the Coolant Solenoid off or on.

[Status] will show active state of [Off] or [On].

OPERATOR'S MANUAL

SCREEN #13, SETUP, Spare Screen

OPERATOR SETUP INFORMATION					
F2 = Back to Operator Setup Functions					
This is a spare screen for future use.					
This is a spare screen for future use.					
This is a spare screen for future use.					
BACK	MENU2	_____	_____	_____	_____
F1	F2	F3	F4	F5	F6

This is a spare screen set up for future use.

F1: BACK -- Press this key to go back 1 screen.

F2: MENU2 - Press this key to return to the Operator Setup Functions Menu Screen.

F3: Not used.

F4: Not used.

F5: Not used.

F6: Not used.

OPERATOR'S MANUAL

SCREEN #14, OPERATOR MODES

```
"AUTO MODES OF OPERATION"
      Select : ADJUST Compensation/Timers
              SINGLE Cut / Full AUTO
[FAULTS!!]
No Faults
MENU      FAULT      _____      _____      ADJUS      S / A
F1         F2         F3         F4         F5         F6
```

F1: MENU --- Return to Main Menu. (See page 2)

F2: FAULT -- Select this Key if the "FAULTS!" prompt is flashing.
(See page 22)

F3: Not Used.

F4: Not used.

F5: ADJUS - Press this key to access the screens to adjust the Wheel
Wear compensation, Sensor to Cut Off Wheel, and Timers and
Machine Oiler. (See page 19).

F6: S / A - Select this Key to access the Single Cut and Full Auto Cut
Options and the select Single or Full Auto. (See page 16)

OPERATOR'S MANUAL

SCREEN #15, OPERATOR MODE - SINGLE CUT

```
--SINGLE CUT / FULL AUTO OPTIONS --  
F1 : STOP CYCLES & Return to Menu  
F3 : for Major Cut Speed = x.xx I.P.M  
F4 : for Break Thru Speed = x.xx I.P.M  
  
STOP      _____ MAJOR  BREAK  _____ SINGL  
F1         F2         F3         F4         F5         F6
```

F1: STOP --- STOP all cutting cycle and return to Auto Modes of Operation Menu. See page 15.

F2: Not used.

F3: MAJOR - Press this key to access the Major Cut Speed value to modify it.

F4: BREAK - Press this key to access the Break Through Speed value to modify it.

F5: Not used.

F6: SINGL - Press this key to access the Single Cut operation screen. See page 17.

OPERATOR'S MANUAL

SCREEN #16, OPERATOR MODE - SINGLE CUT

```
-SINGLE CUT -      Wheel Head Pos= xx.xxx
F1 = STOP - Axis, Cycle, Motor, Coolant
F2 = CYCLE START /REPEAT

      No Faults
      [FAULTS!!]      F6 : Go to Full Auto

STOP      START      _____      BACK      FAULT      AUTO
F1         F2         F3         F4         F5         F6
```

F1: STOP -- STOP Single Cut Cycle, axis movement, wheel motor, and coolant. Then return to the Auto Modes of Operation screen. (See page 15).

F2: START - START Single Cut Cycle and repeat single cut cycle.

F3: Not used.

F4: BACK -- Press this key to go back to Options. (See page 16)

F5: FAULT - Press this key if "Faults!" is flashing. This will return to the Auto Modes of Operation screen. (See page 15)

F6: AUTO -- Press this key to go to the Full Auto Mode. If the Single Cut has been started, the Auto cycle will be active to make the next cut. (See page 18)

Faults status: displays either "No Faults" or "FAULTS!" flashing.

OPERATOR'S MANUAL

SCREEN #17, OPERATOR MODE - FULL AUTO

-FULL AUTO - Wheel Head Pos= xx.xxx					
F1 = CYCLE STOP After Cut Complete					
F2 = CYCLE START					
F3 : Finish Rod & Stop			No Faults		
F6 : Back to Single Cut			[FAULTS!!]		
STOP	START	FINI	_____	FAULT	SINGL
F1	F2	F3	F4	F5	F6

F1: STOP -- Cycle Stop after the rod cut is complete.

F2: START - START Auto Cycle or restart after a cycle stop.

F3: FINI -- Press this key to finish the Rod being Cut and Stop. This will cause cycle stop and shut down the machine.

F3: Not used.

F5: FAULT - Press this key if "Faults!" is flashing. This will return to the Auto Modes of Operation screen. (See page 15)

F6: SINGL - Press this key to go to the Single Cut Mode. If a cut is in progress, it will finish and then be ready to restart or stop. (See page 17)

Faults status: displays either "No Faults" or "FAULTS!" flashing.

OPERATOR'S MANUAL

SCREEN #18, ADJUST COMPENSATION, F6 FROM SETUP SCREEN #14

Auto Modes of Operation					
"COMPENSATIONS and TIMERS"					
+F2/-F3 for SENSOR to WHEEL = x.xxx In.					
If the First Cut Length is short, then					
increase SENSOR to WHEEL value.					
MENU2	+ SEN	- SEN	_____	_____	MORE
F1	F2	F3	F4	F5	F6

F1: MENU2 - Press this key to return to the Auto Modes of Operation Menu Screen. (See page 15)

F2: + SEN -- Press this key to increase the Sensor to Wheel distance.

F3: - SEN -- Press this key to decrease the Sensor to Wheel distance.

The Sensor to Wheel distance determines whether the first rod cut length is the correct amount. If the first rod cut length is short, then increase the Wheel to Sensor amount.

F4: Not used.

F5: Not used.

F6: MORE - Press this key to go to the next set of operator screens.

OPERATOR'S MANUAL

SCREEN #19, ADJUST COMPENSATION, F6 FROM SETUP SCREEN #18

COMPENSATION; Auto Modes of Operation +F2/-F3 for WHEEL Wear Comp = x.xxx In If the Wheel does not cut through the rod, then increase Wheel Wear value.					
BACK	+ WHL	- WHL	_____	_____	MORE
F1	F2	F3	F4	F5	F6

F1: BACK -- Press this key to go back 1 screen.

F2: + WHL -- Press this key to increase the amount of Wheel Wear.

F3: - WHL -- Press this key to decrease the amount of Wheel Wear.

The Wheel Wear amount determines whether the cutting wheel passes through the rod. If the rod has not been cut through, then increase the wheel wear amount.

F4: Not used.

F5: Not used.

F6: MORE - Press this key to go to the next set of operator screens.

OPERATOR'S MANUAL

SCREEN #20, ADJUST COMPENSATION, F6 FROM SETUP SCREEN #19

TIMER/COUNTER-- Auto Modes of Operation					
F3 No Rod Found Timer Preset = xx.x Sec					
F4 : OIL After ?(0 to 1000): xxxx Cycles					
F5 : SHOTS of Oil ? (1 to 5)= x Shots					
BACK	MENU2	TIME	OIL	SHOTS	_____
F1	F2	F3	F4	F5	F6

F1: BACK -- Press this key to go back 1 screen.

F2: MENU2 - Press this key to return to the Auto Modes of Operation Menu Screen. (See page 15)

F3: TIME -- Press this key to revise the amount of time to allow the Rod Pusher to push the rod to the Sensor. The valid range is 3.0 Seconds to 15.0 Seconds.

F4: OIL --- Press this key to access the value of cycles for the machine to make before turning on the Machine Oiler.

F5: SHOTS - Press this key to access the value of shots of oil that the machine oiler will make. The run time for the oiler is set in the engineering section.

F6: Not used.

OPERATOR'S MANUAL

SCREEN #21, FAULTS - SCREENS

GENERAL FALUTS: F6 for detailed Errors					
Axis = OK [Message]					
[Reserved For Exclusive Fault Messages]					
POWER UP Error = None [POWER UP Error]					
E-STOP Error = None [E-Stop DOWN]					
MENU	HOME	CLEAR	POWER	_____	DTAIL
F1	F2	F3	F4	F5	F6

F1: MENU -- Return to the Main Menu. (See page 2)

Fault status: [None or OK] = No faults, take no action.

Reserved for exclusive fault messages: Perform action as stated. This area will prompt the operator for a key to press.

F2: HOME - Press this key to home all Axis if the "Home Required" status is flashing.

F3: ALARM -- Select this Key if Alarm Tag is flashing in upper screen area.

F4: POWER -- Select this Key when "POWER UP ERROR" is flashing.

F5: Not used.

F6: DTAIL - Press this key for detailed screens of errors if needed.

(See page 23.)

When "E-Stop DOWN" is Flashing, **PULL E-STOP.**

OPERATOR'S MANUAL

SCREEN #22, FAULTS - SCREENS

AXIS	Fault = None	[Axis Faults]
OVER	Load Fault = None	[M.S. Over Loads]
Clamp	Closed Pressure Sw. =	[Status]
	Rod End Sensor =	[Status]
	Pusher Jamb Prox. Sw. =	[Status]
BACK	AXIS	OVERL
F1	F2	F3
		F4
		F5
		F6

F1: BACK -- Return to the Fault Menu. (See page 22)

Fault status: [None] = No faults, take no action.

[Fault Type Flashing] = Fault active, select proper Key.

F2: AXIS --- Select this Key when "Axis Faults" if flashing.

(See page 24)

F3: OVERL -- Select this Key when "M.S. Over Loads" is flashing.

(See page 28)

F4: Not used.

F5: Not used.

F6: Not used.

Clamp Closed Pressure Switch displays the status of "Clamp Closed" or "Clamp Opened".

Rod End Sensor displays the status of "Sensor Off" or "Sensor On".

Pusher Jamb Proximity Switch displays the status of "Prox. Off" or "Prox. On".

OPERATOR'S MANUAL

SCREEN #23; FAULTS - SCREENS

AXIS FAULTS: Select Axis to View					
TOOL Bed Axis Faults					
ROD Pusher Axis Faults					
WHEEL Head Axis Faults					
BACK	_____	TOOL	ROD	WHEEL	_____
F1	F2	F3	F4	F5	F6

F1: BACK -- Back to Detailed Fault Screen. (See page 23)

F2: Not Used.

Status: There will be no status of active or none for the axis.

F3: TOOL -- Select this Key to view the Tool Bed axis fault screen.
(See page 25)

F4: ROD --- Select this Key to view the Rod Pusher axis fault screen.
(See page 26)

F5: WHEEL - Select this Key to view the Wheel Head axis fault screen.
(See page 27)

F6: Not used.

OPERATOR'S MANUAL

SCREEN #24; FAULTS - SCREENS - Tool Bed Axis

TOOL BED Axis Position = xxxx.xxx In					
Back / Rear Limit = [Status]					
Forward / Done Limit = [Status]					
Current Position Valid = Ok [NOT VALID]					
Illegal Move Error = None [MOVE ERROR]					
BACK	_____	_____	CLEAR	_____	SET-P
F1	F2	F3	F4	F5	F6

F1: BACK -- Back to Axis Fault screen. (See page 24)

F2: Not used.

F3: Not used.

F4: CLEAR - Press this Key if "MOVE ERROR" is flashing. This will clear the error. Next, the "SET-P" should be pressed. This will set the axis position to Zero.

The axis normal status are shown below:

Back Limit = The status of "Limit ON" means cannot jog back.

Forward Limit = The status of "Limit ON" means cannot jog forward.

Current Position Valid = Ok

Illegal Move Error = Not Active

F5: Not Used.

F6: SET-P - Press this key to set the axis position to Zero.

OPERATOR'S MANUAL

SCREEN #25; FAULTS - SCREENS - Rod Pusher Axis

ROD PUSHER Axis Position = xxxx.xxx In					
Axis Home = Home [NOT HOME]					
Done Limit = Prox OFF [Prox ON]					
Current Position Valid = Ok [NOT VALID]					
Illegal Move Error = None [MOVE ERROR]					
BACK	_____	_____	CLEAR	_____	SET-P
F1	F2	F3	F4	F5	F6

F1: BACK -- Back to Axis Fault screen. (See page 24)

F2: Not used.

F3: Not used.

F4: CLEAR - Press this Key if "MOVE ERROR" is flashing. This will clear the error. Next, the "SET-P" should be pressed. This will set the axis position to Zero.

The axis normal status are shown below:

Axis Home = Home

Done Limit = Prox OFF

Current Position Valid = Ok

Illegal Move Error = Not Active

F5: Not Used.

F6: SET-P - Press this key to set the axis position to Zero.

OPERATOR'S MANUAL

SCREEN #26; FAULTS - SCREENS - Wheel Head Axis

WHEEL HEAD Axis Position = xxxx.xxx In Axis Home = Home [NOT HOME] Upper End Limit = OK [ACTIVE] Current Position Valid = Ok [NOT VALID] Illegal Move Error = None [MOVE ERROR] BACK _____ _____ CLEAR _____ SET-P
--

F1 F2 F3 F4 F5 F6

F1: BACK -- Back to Axis Fault screen. (See page 24)

F2: Not used.

F3: Not used.

F4: CLEAR - Press this Key if "MOVE ERROR" or "Upper End Limit" is flashing. This will clear the error. Next, the "SET-P" should be pressed. This will set the axis position to Zero.

The axis normal status are shown below:

Tool Bed Axis Home = Home

Upper End Limit = Ok

Current Position Valid = Ok

Illegal Move Error = Not Active

F5: Not Used.

F6: SET-P - Press this key to set the axis position to Zero.

OPERATOR'S MANUAL

SCREEN #27; FAULTS - SCREENS Continued

AC MOTOR OVER LOAD STATUS					
CONTACTOR	Wheel Motor:	OK	[TRIPED]		
CONTACTOR	Coolant Motor:	OK	[TRIPED]		
BACK	_____	_____	_____	_____	_____
F1	F2	F3	F4	F5	F6

F1: BACK -- Back to Detailed Fault screen. (See page 23)

CONTACTOR Wheel Motor: - "OK" or if "TRIPPED" then check Coolant Overload Relay.

CONTACTOR Coolant Motor: - "OK" or if "TRIPPED" then check Coolant Overload Relay.

OPERATOR'S MANUAL

SCREEN #28; FAULTS - SCREENS Continued

SPARE FAULT PAGE#28					
LINE2					
LINE3					
LINE4					
LINE5					
_____	_____	_____	_____	_____	_____
F1	F2	F3	F4	F5	F6

OPERATOR'S MANUAL

SCREEN #29; ENGINEERING SCREENS

```
ENGINEERING SECTION  
PRESS  F1  
  
Info: DataDesigner System Software:  
      v52016v.cmd  
  
_____
```

F1 F2 F3 F4 F5 F6

F1: MASKED -- RETURN TO MAIN MENU. (See page 2)

F4: MASKED -- GOTO ENGINEERING (See page 31)

OPERATOR'S MANUAL

SCREEN #30; ENGINEERING SCREENS

```
"ENGINEERING SETUP FUNCTIONS"

F5 ;Exit to Program Operator Interface

F6 ;MORE -To Change More Resister Values

MENU   _____  _____  ALARM  PROG  MORE

F1      F2      F3      F4      F5      F6
```

This screen and the following screens are to be accessed by a SUPERVISOR or ENGINEERING ONLY!

F1: MENU -- Return to the Main Menu. (See page 2)

F2: Not used.

F3: Not used.

F4: ALARM - Reset Any Alarm Tag that Exceeds an Over or Under Value.

F5: PROG - Press this key to exit the run mode of the Operator Interface and enter the Setup/Program mode.

F6: MORE - Press this key to view more screens to change Register Values to customize for each Machine. (See page 32)

OPERATOR'S MANUAL

SCREEN #31; ENGINEERING SCREENS

```
No Rod FOUND Timer Preset; Range 5-12Sec
Constant = 7.0 Sec ; Preset = xx.x Sec
Spare Future Timer
Constant = x.x Sec ; Preset =
      "ENGINEERING Functions"

BACK   _____  FOUND   TMR-2   _____  MORE
F1      F2          F3      F4          F5          F6
```

F1: BACK -- Return to the previous screen. (See page 31)

F2: Not Used.

F3: FOUND - Press this key to access the register to write a New Value.

F4: TMR-2 - Future use, press to Write New Value.

F5: Not Used.

F6: MORE -- Press this key to view more screens to change Register Values to customize for each Machine. (See page 33)

OPERATOR'S MANUAL

SCREEN #32; ENGINEERING SCREENS

Tool Bed -- "Index TIME" variable PLC Calcultes; ROD DIA/TIME= [Velocity] Range: 2.0 sec [Fast] to 6.0 sec [Slow] Default = 4.0 Sec ; Preset = x.x Sec "ENGINEERING Functions"					
BACK	ENG'R	_____	TIME	_____	MORE
F1	F2	F3	F4	F5	F6

F1: BACK -- Return to the previous screen. (See page 32)

F2: ENG'R -- Back to Engineering Screen. (See page 31)

F3: Not Used.

F4: TIME - This value adjusts the Tool Bed time to index the next part.

F5: Not Used.

F6: MORE -- Press this key to view more screens to change Register Values to customize for each Machine. (See page 34)

OPERATOR'S MANUAL

SCREEN #33; ENGINEERING SCREENS

```
Minimum ROD DIAMETER;
Default = 0.062 Dia ; Preset = x.xxx Dia
Maximum ROD DIAMETER;Range = 0.500-1.062
Default = 1.062 Dia ; Preset = x.xxx Dia
"ENGINEERING Functions"

BACK      ENG'R      _____      MIN      MAX      MORE
F1         F2         F3         F4         F5         F6
```

F1: BACK -- Return to the previous screen. (See page 33)

F2: ENG'R -- Back to Engineering Screen. (See page 31)

F3: Not Used.

F4: MIN --- Select to key to write new value for the Minimum Rod Diameter.

F5: MAX --- Select to key to write new value for the Maximum Rod Diameter.

F6: MORE -- Press this key to view more screens to change Register Values to customize for each Machine. (See page 35)

OPERATOR'S MANUAL

SCREEN #34; ENGINEERING SCREENS

```
Minimum CUT LENGTH;
Default = 0.060 In ; Preset = xx.xxx In
Maximum CUT LENGTH;Range = 12.000-15.000
Default = 14.000 In ; Preset = xx.xxx In
"ENGINEERING Functions"

BACK      ENG'R      _____      MIN      MAX      MORE

F1        F2        F3        F4        F5        F6
```

F1: BACK -- Return to the previous screen. (See page 34)

F2: ENG'R -- Back to Engineering Screen. (See page 31)

F3: Not Used.

F4: MIN --- Select to key to write new value for the Minimum Rod Cut Length.

F5: MAX --- Select to key to write new value for the Maximum Rod Cut Length. Range is dependent upon machine build.

F6: MORE -- Press this key to view more screens to change Register Values to customize for each Machine. (See page 36)

OPERATOR'S MANUAL

SCREEN #35; ENGINEERING SCREENS

```
Minimum CUT SPEED;
Default = 0.10 IPM ; Preset = xx.xx IPM
Maximum CUT SPEED;
Default = 4.01 IPM ; Preset = xx.xx IPM
      "ENGINEERING Functions"

BACK      ENG'R      _____      MIN      MAX      MORE
  F1          F2          F3          F4          F5          F6
```

F1: BACK -- Return to the previous screen. (See page 35)

F2: ENG'R -- Back to Engineering Screen. (See page 31)

F3: Not Used.

F4: MIN --- Select to key to write new value for the Minimum Cut Speed.

F5: MAX --- Select to key to write new value for the Maximum Cut Speed.

F6: MORE -- Press this key to view more screens to change Register Values to customize for each Machine. (See page 37)

OPERATOR'S MANUAL

SCREEN #36; ENGINEERING SCREENS

```
Minimum NIP AMOUNT
Default = 0.062 In ; Preset = xx.xxx In
Oiler cycle Time Per Shot of Oil (5-10)
Default 5 Minutes ; Preset = xx Minutes
"ENGINEERING Functions"
BACK    ENG'R    _____    NIP    MINUT    MORE
F1      F2      F3      F4      F5      F6
```

F1: BACK -- Return to the previous screen. (See page 36)

F2: ENG'R -- Back to Engineering Screen. (See page 31)

F3: Not Used.

F4: NIP -- Select this key to write a value for the Minimum Nip amount.

F5: MINUT - Press this key to write a value for the cycle time of the oiler motor from the specifications.

F6: MORE -- Press this key to view more screens to change Register Values to customize for each Machine. (See page 38)

OPERATOR'S MANUAL

SCREEN #37; ENGINEERING SCREENS

```
Minimum BREAK THRU (%) of Rod Diameter
Default = 50 % ; Preset = xx %
Maximum BREAK THRU (%) of Rod Diameter
Default = 95 % ; Preset = xx %
"ENGINEERING Functions"
BACK      ENG'R      _____  MIN      MAX      MORE
F1        F2        F3        F4        F5        F6
```

F1: BACK -- Return to the previous screen. (See page 37)

F2: ENG'R -- Back to Engineering Screen. (See page 31)

F3: Not Used.

F4: MIN --- Select to key to write a new value for the Minimum Break through percentage of the rod diameter. The valid range is 50% to 75%.

F5: MAX --- Select to key to write a new value for the Maximum Break through percentage of the rod diameter. The valid range is 80% to 95%.

F6: MORE -- Press this key to view more screens to change Register Values to customize for each Machine. (See page 39)

OPERATOR'S MANUAL

SCREEN #38; ENGINEERING SCREENS

WHEEL WEAR Compensation will change with each +/- key by the Incremental amount of Default = 0.001 In ; Preset = x.xxx In "ENGINEERING Functions"					
BACK	ENG'R	_____	INCRE	_____	MORE
F1	F2	F3	F4	F5	F6

F1: BACK -- Return to the previous screen. (See page 38)

F2: ENG'R -- Back to Engineering Screen. (See page 31)

F3: Not Used.

F4: INCRE - Press this key to access the register to change the
incremental value for the Wheel Wear Compensation amount.

F5: Not Used.

F6: MORE -- Press this key to view more screens to change Register
Values to customize for each Machine. (See page 40)

OPERATOR'S MANUAL

SCREEN #39; ENGINEERING SCREENS

Rod End Sensor to Wheel Side Compensation will change with each +/- key by the Incremental amount of: Default = 0.002 In ; Preset = x.xxx In "ENGINEERING Functions"					
BACK	ENG'R	_____	INCRE	_____	MORE
F1	F2	F3	F4	F5	F6

F1: BACK -- Return to the previous screen. (See page 39)

F2: ENG'R -- Back to Engineering Screen. (See page 31)

F3: Not Used.

F4: INCR - Press this key to access the register to change the *incremental* value for the Rod Edge Sensor to Wheel Side compensation amount.

F5: Not Used.

F6: MORE -- Press this key to view more screens to change Register Values to customize for each Machine. (See page 41)

OPERATOR'S MANUAL

SCREEN #40; ENGINEERING SCREENS

WHEEL HEAD Over Travel Software Limit: Default = 1.515 In ; Preset = x.xxx In					
WHEEL HEAD Backlash Compensator: Default = 0.200 In ; Preset = x.xxx In "ENGINEERING Functions"					
BACK	ENG'R	_____	WH-OT	WH-BL	MORE
F1	F2	F3	F4	F5	F6

F1: BACK -- Return to the previous screen. (See page 40)

F2: ENG'R - Back to Engineering Screen. (See page 31)

F3: Not Used.

F4: W-O-T - Press this key to access the register to change the Wheel Head Over Travel Software Limit. This distance should be the measured distance from a new wheel, with the Wheel Head axis at home, to the back of the clearance slot.

F5: W-B-C - Press this key to access the register to change the Wheel Head Backlash Compensation.

F6: MORE -- Press this key to view more screens to change Register Values to customize for each Machine. (See page 42)

OPERATOR'S MANUAL

SCREEN #41; ENGINEERING SCREENS

Wheel to Rod Advance Safety Air Gap: Default = 0.050 In ; Preset = x.xxx In Wheel Over Cut of Rod amount: Default = 0.050 In ; Preset = x.xxx In "ENGINEERING Functions"					
BACK	ENG'R	_____	AIR-G	OVCUT	MORE
F1	F2	F3	F4	F5	F6

F1: BACK -- Return to the previous screen. (See page 41)

F2: ENG'R -- Back to Engineering Screen. (See page 31)

F3: Not Used.

F4: AIR-G - Press this key to access the register to change the Wheel to Rod Advance Safety Air Gap amount. This is the amount of gap that remains after the rapid travel toward the rod.

F5: OVCUT - Press this key to access the register to change the Wheel Over Cut amount. This is the extra amount of Wheel Head travel that will be applied to the rod diameter distance.

F6: MORE -- Press this key to view more screens to change Register Values to customize for each Machine. (See page 43)

OPERATOR'S MANUAL

SCREEN #42; ENGINEERING SCREENS

```
ORIGINAL Distance from the VEE CENTER
to the O.D. of a 8" Cut Off Wheel is:
Default = 0.875 In ; Preset = x.xxx In

"ENGINEERING Functions"

BACK      ENG'R      _____  VEE-W      _____  MORE
F1        F2        F3        F4        F5        F6
```

F1: BACK -- Return to the previous screen. (See page 42)

F2: ENG'R -- Back to Engineering Screen. (See page 31)

F3: Not Used.

F4: VEE/W - Press this key to access the register to change the Original Vee Center to New Wheel Outside Diameter amount. The PLC uses this dimension to calculate the moves to perform on the rods.

F5: Not Used.

F6: MORE -- Press this key to view more screens to change Register Values to customize for each Machine. (See page 44)

OPERATOR'S MANUAL

SCREEN #43; ENGINEERING SCREENS

Sensor to Wheel OFFSET Comp. Per O.D.					
Sensor to Wheel Reference = x.xxx In					
1/16" OD ; Ref. = xx.xxx In					
1/8" OD ; Ref. = xx.xxx In					
1/4" OD ; Ref. = xx.xxx In					
BACK	REF.	1/16"	1/8"	1/4"	MORE
F1	F2	F3	F4	F5	F6

F1: BACK -- Return to the previous screen. (See page 42)

F2: REF. - Press this key to write the value of Sensor to Wheel distance for Rod diameter to be used. The operator can change this value when they look up the references from their chart.

F3: 1/16" - Press this key to write the value of the Sensor to Wheel distance for a 1/16" diameter rod.

F4: 1/8" -- Press this key to write the value of the Sensor to Wheel distance for a 1/8" diameter rod.

F5: 1/4" -- Press this key to write the value of the Sensor to Wheel distance for a 1/4" diameter rod.

F6: MORE -- Press this key to view more screens to change Register Values to customize for each Machine. (See page 43)

OPERATOR'S MANUAL

SCREEN #44; ENGINEERING SCREENS

Sensor to Wheel Comp. Values Per O.D.					
3/8" OD ; Ref. = xx.xxx In					
1/2" OD ; Ref. = xx.xxx In					
3/4" OD ; Ref. = xx.xxx In					
1" OD ; Ref. = xx.xxx In					
BACK	3/8"	1/2"	3/4"	1"	ENG'R
F1	F2	F3	F4	F5	F6

F1: BACK -- Return to the previous screen. (See page 42)

F3: 3/8" -- Press this key to write the value of the Sensor to Wheel distance for a 3/8" diameter rod.

F4: 1/2" -- Press this key to write the value of the Sensor to Wheel distance for a 1/2" diameter rod.

F5: 3/4" -- Press this key to write the value of the Sensor to Wheel distance for a 3/4" diameter rod.

F6: 1" -- Press this key to write the value of the Sensor to Wheel distance for a 1" diameter rod.

F6: ENG'R - Back to Engineering Screen. (See page 31)

OPERATOR'S MANUAL

Rod End Sensor to Wheel Calculations

The distance from the Proximity Switch to the wheel can be established by carefully pushing a selected diameter rod up to the sensor to find where the signal led activates.

First, adjust the sensor gain by placing the edge of a 1/16" diameter rod to the center of the sensor target.

The distances will vary with the sensor gain adjustment. This will be a static measurement to provide a starting distance.

The Rod End Sensor status can be observed by entering the Fault section of the Operator Interface Panel and then selecting F6 (DETAIL). This will allow the operator or technician to easily view the status of the sensor pickup.

The proximity switch sensing distance is proportional to the mass of the target (carbide rod diameter).

The Distance Chart below may change from Machine to Machine because of the mechanical position of the Proximity Switch and the Amplifier Gain Adjustment.

Stock Dia.	Sensor 1/16"Ref.	Difference From Ref.
1/16"	x.xxx"	+0.000"
1/8"		+0.062"
1/4"		+0.145"
3/8"		+0.135"
1/2"		+0.105"
3/4"		+0.085"
1"		+0.020"

Test Run: 1-14-99

Revised: 3/30/2002

Greg Maynard; EET